CSE 4355/5355 - Mechatronics Lab 7

Yasasvi Vanapalli

1002182593

Anaf Mahbub

1001952603

Introduction: This report outlines the steps, results, and code implementation of a lab project aimed at measuring force and mass using a strain gauge and the HX711 analog-to-digital (A/D) converter. The project involves configuring the hardware, soldering and gluing a strain gauge to an aluminum beam, reading the data through a microcontroller, and empirically deriving an equation for converting A/D results to physical force and mass measurements.

- **1. Circuit Assembly:** The circuit involves connecting the HX711 device to the controller and setting up the strain gauge as described:
 - DATA and PD_CLK lines of HX711 are connected to the controller.
 - 350-ohm resistors are connected between:
 - o E+ to A+
 - o E+ to A-
 - o E- to A+
 - The strain gauge block uses:
 - RED: Excitation + (E+)
 - BLACK: Excitation (E-)
 - GREEN: Signal + (A+)
 - YELLOW: Signal (A-)
 - The **BLACK** jack is connected to E-, and the **YELLOW** jack to A-.

2. Strain Gauge Preparation:

- 30 AWG bare wires were soldered to the strain gauge while it rested on a glass plate for stability.
- The strain gauge was then glued to the aluminum beam, ensuring strong adhesion for accurate strain measurement.
- The wires were clipped to the **BLACK** and **YELLOW** banana jacks with toothless alligator clips to maintain secure connections.
- **3. Microcontroller Configuration:** The PD_CLK was configured as a General-Purpose Output (GPO), and the DATA line was configured as a General-Purpose Input (GPI).

4. Code Implementation: The following code was used to read the voltage data from the HX711 and display the raw data, calculated mass, and force:

```
С
Copy code
#include <stdio.h>
#include <stdint.h>
#include <stdbool.h>
#include "wait.h"
#include "uart0.h"
#include "tm4c123gh6pm.h"
#include "gpio.h"
#include "clock.h"
#define DATA PORTC,6
#define PD_CLK PORTC,7
uint32_t data = 0;
void initHw() {
  initSystemClockTo40Mhz();
  enablePort(PORTC);
  _delay_cycles(3);
  selectPinDigitalInput(DATA);
  enablePinPulldown(DATA);
  selectPinPushPullOutput(PD_CLK);
}
// main function
void main(void) {
  initHw();
```

initUart0();


```
setUart0BaudRate(115200, 40e6);
uint8_t i;
char str[40];
float mass = 0, force = 0;
while(true) {
  if(getPinValue(DATA) == 1) {
    data = 0;
    for (i = 0; i < 24; i++) {
      setPinValue(PD_CLK, 1);
      waitMicrosecond(40);
      data <<= 1;
      data |= getPinValue(DATA);
      setPinValue(PD_CLK, 0);
      waitMicrosecond(1);
    }
    setPinValue(PD_CLK, 1);
    waitMicrosecond(40);
    setPinValue(PD_CLK, 0);
    snprintf(str, sizeof(str), "Raw Data: %d", data);
    putsUart0(str);
    putsUart0("\n");
    mass = abs(data - 12001104);
    snprintf(str, sizeof(str), "Mass: %f", (mass / 13) - 175);
    putsUart0(str);
    putsUart0("\n");
    snprintf(str, sizeof(str), "Force: %f", mass * 9.81);
    putsUart0(str);
    putsUart0("\n\n");
```

```
waitMicrosecond(1000000);
}
}
```


- **5. Data Acquisition and Results:** Empirical data was collected by placing known weights on the beam to calibrate the A/D output to physical units of force (N) and mass (g). The derived equation for converting the 24-bit result was calibrated and refined to achieve accurate outputs.
- **6. Observations and Error Analysis:** When pressing on the end of the beam, a force was detected, indicating compression and tension in the strain gauge. Additional strain gauges arranged in a full Wheatstone bridge could be added to eliminate the effect of non-uniform stress and provide temperature compensation.

Conclusion: The lab successfully demonstrated how to set up and calibrate a strain gauge system using an HX711 A/D converter. The process included hardware preparation, soldering, gluing, circuit connection, and programming. The measured data was accurately converted to real-world mass and force units through empirical calibration.

Observations:



• 224g weight



• 450g weight:

```
## Data | 1902/00

### Dat
```

• 675g weight:

900g weight:

```
## COMMINIST
FORCE: 46430.730000

RAW Data: 11999308
Hass: 63.92300
Force: 3046.860000

RAW Data: 11998208
Hass: 81.92308
Force: 3046.9760000

RAW Data: 11998208
Hass: 81.92308
Force: 2046.9760000

RAW Data: 11998208
Hass: 81.92308
Force: 2056.620000

RAW Data: 11998284
Hass: 81.92308
Force: 2056.960000

RAW Data: 11998284
Hass: 81.92308
Force: 2056.960000

RAW Data: 11980836
Hass: 91.92308
Force: 147326.800000

RAW Data: 11980836
Force: 147326.800000

RAW Data: 11980839
Force: 147326.800000

RAW Data: 11980839
Force: 147326.900000

RAW Data: 11980849
Hass: 90.300713
Force: 147326.800000

RAW Data: 11980849
Force: 147326.900000

RAW Data: 11980849
Force: 147326.900000

RAW Data: 11980849
Force: 147326.900000

RAW Data: 11980841
Force: 147326.900000

RAW Data: 11980841
Force: 147326.900000

RAW Data: 11980844
Force: 147327.9000000

RAW Data: 11980844
Force: 147327.9000000
```